


## RAJKOT DIESEL MACHINES

## TANK LEVEL & LEAKS DETECTION MONITORING - ALARM





## RAJKOT DIESEL MACHINES TR. EST.

Web: www.rajkotdiesel.com

P.O. Box: 30741, Industrial area - 01, Sharjah, UAE. Tel: +971 65523589, Mob: +971504628276.

RAJKOT MARINE L.L.C.

P.O. Box: 5861, Jaraf area - 01, Ajman, UAE. Tel: +971 67487580, Mob: +971504628276. Email: redimate@eim.ae, joya.gomez@rajkotmarine.com. Email: redimate@eim.ae, joyantony@rajkotmarinelk.ae. Web: www.rajkotmarine.com

4JB AUTOMATION & POWER CONTROLS PVT. LTD.

P.O. Box: 682028, Arakad Road, Kochi, Kerala, India. Tel: +91 4842808380, Mob: +91 9500903083. Email: redimate@eim.ae, sales@rajkotmarinelic.ae. Web: www.4jbautomation.com

Multi Purpose: The tank alarm can be used wherever a high, low or bund level alarm is required in either vertical or

horizontal tanks.

Alarm Condition: Float activated switches detect alarm conditions, a maximum of 3 float switches can be installed, monitoring high,

low or bund levels.

Suits Most Fuels: The tank alarm is suitable for many liquids including diesel, gasoil, oils, & water.

Simple to Install: Easy installation via a wall mounting bracket & fast wiring using our plug & socket field connections.

Configuration: Switches installed in the main unit allow easy float configuration.



P.O. Box: 30741, Industrial area - 01, Sharjah, UAE. Tel: +971 65523589, Mob: +971504628276.

Email: redimate@eim.ae, joya.gomez@rajkotmarine.com. Email: redimate@eim.ae, joyantony@rajkotmarinelk.ae. Email: redimate@eim.ae, sales@rajkotmarinelic.ae. Web: www.rajkotdiesel.com

## RAJKOT MARINE L.L.C.

P.O. Box: 5861, Jaraf area - 01, Ajman, UAE. Tel: +971 67487580, Mob: +971504628276. Web: www.rajkotmarine.com

4JB AUTOMATION & POWER CONTROLS PVT. LTD. P.O. Box: 682028, Arakad Road, Kochi, Kerala, India. Tel: +91 4842808380, Mob: +91 9500903083.

Web: www.4jbautomation.com